

GRB2000: SEMI- AUTOMATIC STRAPPING MACHINE



The GRB200 is a semi-automatic horizontal strapping machine for pallets. It is easy to positioning the plastic strap by means of a folding arm. The launching, tensioning and sealing of the plastic strap is activated by a remote control.

The GRB2000 is capable of exerting pressure to stabilize any type of pallet load through a tensioning system. The plastic strap tensioning capability is versatile thanks to an operating lever that allows the user to decide whether to proceed in automatic or manual mode. The GRB2000 is manufactured in accordance with occupational health and safety regulations.

Technical features

Joining system	Thermowelding
Binding material	Polypropylene strap
Coil dimensions	Ø int. 200 x Ø ext. 450 x Width 190 mm.
Strap width	9/12/15 mm. (optional)
Strap tension	Up to 70 Kgf.
Strap thickness	From 0.45 to 0.70 mm.
Tensioning	Electronic
Binding speed	2.2 sec/cycle
Power supply	220 single-phase, 50 Hz, 0.4 Kva.
Minimum strap height	170 mm.
Maximum package to be strapped	h 2210 mm.
Strapping machine weight	Approx. 160 kg.
Worktops	Smooth